

Surface Hub 3 site readiness guide

Scope

 Note

This article applies to [new Surface Hub 3 devices](#), Surface Hub 2S devices [upgraded with the Surface Hub 3 Compute Cartridge](#) and Surface Hub 2S devices [software-migrated to the Teams Rooms on Windows platform](#).

 **Expand table**

Article	Description
Surface Hub Site planning	Review room considerations and planning for peripherals.
Surface Hub quick start	Get an overview of required steps to unpack and start Surface Hub 3.
Surface Hub ports and keypad overview	Get details for all physical buttons, I/O ports, keypad power, and selection controls.
Adjust Surface Hub brightness, volume, and input	See how to use the onscreen display to adjust brightness and other settings.
Install & mount Surface 50" models of Surface Hub 2S or Surface Hub 3	Learn about licensed accessories to install and mount Surface Hub 3 50-inch devices.
Install and mount Surface Hub 3 85"	Review recommended guidance for installing Surface Hub 3 85-inch devices.
Customize wall mount of Surface Hub	Learn how to custom install without licensed mounting accessories.

Learn more

- [What's new for Surface Hub 3](#)
- [Get started with Surface Hub running Microsoft Teams Rooms on Windows](#)
- [First-time setup for Surface Hub running Microsoft Teams Rooms on Windows](#)

