




Scan to watch
the installation video.



MeetingBar A40



Quick Start Guide V1.7

English | Deutsch | Français | Español


CONTENT

English.....	1
Deutsch.....	13
Français.....	25
Español.....	37


1 Package Contents




MeetingBar A40




Power Adapter
(48 V/2 A)
(3.5 m, 11.48 ft)




CAT5e UTP
(RJ45 - RJ45) Cable
(3 m, 9.84 ft)



HDMI 2.0 Cable x 2
(1.8 m, 5.91 ft)




Mounting Bracket




TV-Clip Mount




Cable Cover



Screw x 2
6 × 30 mm, white,
Polyamide



Screw x 2
T4 × 30 mm,
FAHOZN3+



Screw x 2
1/4 inch × 12 mm



Screw x 1
1/4 inch × 13 mm



Screw x 2
1/4 inch × 8 mm



Screw x 2
M2 × 4 mm,
CMH0ZN3+




Silicone Pad x 2
(38 × T1.2 mm)



Velcro x 2
(One is on the M-2)



Cable Tie x 5
(20 × 200 mm)



Quick Start Guide

Optional Packages



VCR11 and AAA Battery × 2



CTP25 Package





Table-top Stand




We recommend that you use these three accessories together.



MeetingDisplay



MD-Wallmount




MD-AVBracket-S



We recommend that you use the accessories provided or approved by Yealink. The use of unapproved third-party accessories may result in reduced performance.

2 Hardware Interface Instructions




No.	Item	Description
1	Camera	Camera with an electric privacy shutter.
2	LED Indicator	Indicate the device status.
3	Internet	• Connect to a Yealink MeetingDisplay's LAN port to access the network, provided that the MeetingDisplay is connected to the Internet. • Connect directly to the network for Internet access.
4	VCH	• Connect to a Yealink CTP Touch Panel. • Connect to a microphone. • Connect to a PoE switch.
5	DC48V	Connect to a power adapter.
6, 7	HDMI 1 & HDMI 2	• Connect to a display for video image output. • You need to use HDMI 1 Port first when using only one display.
8	USB-C 3.0 (back)	Connect to a PC for content sharing or BYOD.

9	USB-A 2.0	• Connect to a Yealink MeetingDisplay to synchronize configurations and integrate features. • Connect a USB accessory, such as a mouse.
10, 11	Line-in/Line-out	Connect to an audio output/input device via a 3.5 mm audio cable.
12	Reset Key	Reset to factory defaults.
13	Security Slot	Connect a universal security cable to the device so that you can lock it down.
14	USB-C 3.0 (side)	Connect to a Yealink Wireless Presentation Pod for pairing.


3 Basic Connection

- Display requirement: A resolution of 1080p or higher, and a port that supports HDMI 1.4 or higher.
- If you only need to use one display, please connect to HDMI 1 port.



4 Connect MeetingDisplay with A40 (Optional)

- USB 2.0 (A-B) cable is included in MD-AVBracket-S's package.
- If the CAT5e cable from MeetingBar A40 is not connected to the LAN port of MeetingDisplay, then it should be connected to an external network port.




5 Connect CTP25 with A40 (Optional)

Option 1: Direct Connection with an Ethernet Cable


Use a network cable to connect the CTP25 to the A40.

MeetingBar A40




Option 2: Connection on the Same LAN


A40 and CTP25 need to be on the same LAN.




6 Assemble Cable Cover




- 1 Find the two slots on the back of A40.



- 2 Fit part A of the cable cover into the slots.



- 3 Assemble part B and fix the screws.





7 Installation

Option 1: Mount on Yealink MeetingDisplay



Installation Video


- You need to purchase MeetingDisplay and MD-AVBracket-S separately. For installation, please refer to the **MD-AVBracket-S Quick Start Guide** included in the corresponding package.
- Another 6 screws (1/4 inch x 12 mm) are included in the MD-AVBracket-S's package.





Option 2: Mount on a wall

Step 1: Determine A40 position.


The mounting height affects your camera view. The recommended installation height is 110 cm above the ground, and the reserved distance between A40 and TV should be greater than 1 cm.



Step 2: Mount the A40 to the wall.




Hole depth: 30 mm (0.098ft) Hole diameter: 6 mm (0.02ft)




Option 3: Mount above a TV or a display

- The M-2 bracket can be inserted into the M-1 in two directions. Here, we will focus on one direction for illustration.
- Due to device weight, it is advisable to avoid mounting the device on slim TVs to prevent potential falls or damage to the screen.




Option 4: Put on a flat surface



Option 5: Embed in the wall




- The mounting height affects your camera view. The recommended installation height is 110 cm above the ground.
- Keep the front of the A40 flush with the wall surface.
- The recommended on the left, right, and top sides of the A40 is less than 0.5 cm.
- Leave a 5 ± 0.5 cm distance between the back of the A40 and the wall surface for cable connections.




Option 6: Mount on the table-top stand



Refer to the **8 Adjust the Camera Tilt** section for bracket adjustment.



8 Adjust the Camera Tilt



9 VCR11 (Optional)



You can use the remote control (not applicable to Zoom version) or CTP25 to operate the A40. If a touch display device is connected, you can also operate the A40 directly on the touch screen.

- 1 Power Key*
- 2 Record Video Key*
- 3 Layout Key: Adjust the layout during the meeting*
- 4 Custom Key: Switch to General Mode (BYOM)*
- 5 Volume Key: Zoom In/Out: OK Key: Navigation Key:
- 6 Mute Key
- 7 Home Key: Return to the home screen when not on a call. Open the menu bar during the call.*
- 8 Return Key
- 9 Dial Key
- 10 Delete Key
- 11 Hang up Key
- 12 Character Keys



* Coming Soon
The supported keys in different modes may be various.


10 Pair with the CTP25 (Optional)

For a better pairing experience, we recommend starting the A40 first and then the CTP25.

Pair Manually

If you purchased a bundle kit or connected CTP25 to A40 via a network cable, A40 and CTP25 would be paired automatically. You can go to **Initialization** directly.

On the CTP25, enter the IP address and pairing code of the A40 on display.



Initialization

1. If the CTP25 is restored to factory settings, you need to change the default password (0000) of the CTP25.
2. Initialize **Language**, **Network**, **Time Zone** and **Auto Update**, and select the desired platform. If you select **General Mode (BYOM)**, refer to the **11 General Mode (BYOM)** section.
3. Change the default password (0000) of the A40.

Account Login

Contact the corresponding service provider to obtain an account.


Follow the prompts on A40 and CTP25 to sign in to the same account.

11 General Mode (BYOM)

1. Do one of the following to select **General Mode (BYOM)**:
 - When selecting a platform during power-on initialization, select **General Mode (BYOM)**.
 - After logging in, reset to factory to switch platforms.
2. Refer to the **12 Content Sharing and BYOD** section to share content or use the BYOD function.

12 Content Sharing and BYOD (Optional)

Content Sharing



BYOD

Go to the web interface, and enter **System** > **UC Provider** to enable **BYOD Enable**.

Use the USB-C cable to connect the CTP25 to the PC, and follow the prompts to enter BYOD mode.

13 Update the Firmware

Auto Update

Do one of the following:

- During power-on initialization, turn on **Auto Update**.
- In settings, turn on **Auto Update**.

Manual Update

Update the firmware of MeetingBar A40 and CTP25 separately.

1. Obtain the IP address.
2. Open a web browser and enter the device's IP address in the address bar. For example, <https://10.82.24.11/>, and press **Enter**.
3. Enter the administrator username and the password, and click **Login**. (The default user name is "admin", the password is "0000").
4. Go to **System** > **Update**.
5. On the right side of **Device Firmware**, click **Select File** to upload the desired firmware.
6. Click **Update**.

Please get the latest firmware at <https://support.yealink.com/>.

Declaration of Conformity

We,

YEALINK(XIAMEN) NETWORK TECHNOLOGY CO.,LTD

Address: No.666 Hu'an Rd. Huli District Xiamen City, Fujian, P.R. China

Manufacturer: YEALINK(XIAMEN) NETWORK TECHNOLOGY CO.,LTD

Address: No.666 Hu'an Rd. Huli District Xiamen City, Fujian, P.R. China

DATE: 26 / May / 2024

declare that the product

Type: Video Conferencing Endpoint

Model: MeetingBar A40

meets the essential requirements and other relevant provisions according to the following EC

directive **Directive: 2014/30/EU, 2014/35/EU, RED 2014/53/EU**

Conformity

The product complies with the following standards:

Safety : **EN 62368-1:2020+A11:2020**

EMC: **EN 55032:2015+A11:2020**

EN 55035:2017+A11:2020

EN IEC 61000-3-2: 2019+A1:2021

EN 61000-3-3: 2013+A2:2021

Radio:ETSI EN 301 489-1 V2.2.3,

ETSI EN 301 489-3 V2.3.2 (2023-01) ,

ETSI EN 301 489-17 V3.2.4,

ETSI EN 300 328 V2.2.2;

ETSI EN 301 893 V2.1.1

ETSI EN 300 440 V2.2.1

Health :EN IEC 62311:2020&EN 50665:2017;

Harmonized: UN-EN62321

Directive 2011/65/EU and (EU)2015/863 of the European Parliament and of the Council of 8 June 2011 and 4 June 2015 on the restriction of the use of certain hazardous substances in electrical and electronic equipment(RoHS 2.0)

Directive 2012/19/EU of the European Parliament and of the Council of 4.July.2012 on Waste electrical and electronic equipment(WEEE)

Regulation (EC) No.1907/2006 of the European Parliament and of the Council of 18.December.2006 on Registration, Evaluation, Authorization, and Restriction of Chemicals (REACH)

The declaration of conformity is issued under the sole responsibility of the manufacturer

NAME: Huahu Wang

DATE:

TITLE: Manager

Addr: No.666 Hu'an Rd. Huli District Xiamen City, Fujian, P.R.
China

Tel: +86-592-5702000
Fax: +86-592-5702455

About Yealink

Yealink (Stock Code: 300628) is a global-leading provider of Unified Communication & Collaboration Solutions specialized in video conferencing, voice communications, and collaboration, dedicated to helping every person and organization embrace the power of "Easy Collaboration, High Productivity".

With best-in-class quality, innovative technology, and user-friendly experiences, Yealink is one of the best providers in more than 140 countries and regions, ranks No.1 in the global market share of IP Phone, and is the Top 5 leader in the video conferencing market (Frost & Sullivan, 2021).

Technical Support

Visit Yealink WIKI (<http://support.yealink.com/>) for firmware downloads, product documents, FAQ, and more. For better service, we sincerely recommend you to use Yealink Ticketing system (<https://ticket.yealink.com>) to submit all your technical issues.



430111000080

YEALINK(XIAMEN) NETWORK TECHNOLOGY CO.,LTD.

Web: www.yealink.com

Addr: No.666 Hu'an Rd,Huli District Xiamen City, Fujian, P.R.
China

Copyright©2026 Yealink Inc. All right reserved.