


Quick User Guide in General Mode (BYOM)

Home Interface



No.	Description
1	Device name and status.
2	Click the sidebar menu button to enter the shortcut tools. Please refer to the figure below for details.
3	Time and date.
4	Casting code. Enter this code in the YeaCast app to start casting.
5	Applications. • Whiteboard Create a whiteboard and start writing. • Cast Screen Share your screen via the hardware endpoint. • BYOD Use the MeetingBoard Pro's display as a peripheral for third-party UC meetings through the BYOD feature.


	• Apps Select to view other apps.
6	Swipe up to access the task manager. Currently supported only on the MeetingBoard 75 Pro.



No.	Description
1	• Home: Return to homepage. • Settings View device IP, change device settings, etc. For example, display, camera, audio, network, etc., can be configured. • Annotation In any interface on MeetingBoard Pro, you can add annotations to the content of the page. • Camera Control: Adjust the camera manually, or use camera AI features such as Auto Framing, etc. • Screenshot Select to capture the current screen. • Help Center Cover guides and FAQs to help you get started quickly and master the use of MeetingBoard Pro.

	• Task Quickly switch or clear the currently running tasks of MeetingBoard Pro.
2	Adjust the brightness.
3	Adjust the speaker volume.
4	Select other applications.

Whiteboard Interface



No.	Description
1	• Open Open a local/unsaved whiteboard file. • Export Export the whiteboard content. After configuring the email service, you can export the whiteboard content to your email. • Settings Set your whiteboard. You can change the whiteboard background color and enable the ink-to-shape and multi-inking feature.
2	• Pen Select different pens to write with and change the pen's line thickness and color. • Eraser

	Select different erasing methods based on the size of the area you want to erase: large area erasing, small area erasing, tiny area erasing, erasing with the pen tip, or one-click clear. • Empty Select the feature to clear all your current whiteboard content. • Select Select the feature and use your finger or stylus to draw a selection around the ink strokes you want to move, zoom in, copy, or delete. • Undo Undo your operations. • Redo Redo your operations. • Insert Insert local pictures or pictures from a USB flash drive into the whiteboard, and you can also insert regular graphics and sticky notes into the whiteboard. • Pages Select the feature to change your whiteboard pages. • Add Select the feature to add new whiteboard pages. • Overlook Select the feature to display the drawn content area on the whiteboard with a mini-map, allowing for clear visibility of the content beyond the current view, and enabling quick focus and positioning within the selected content area.
3	Exit the whiteboard application.