Yealink



# Steel-edge Shipping Packing Crate

## Quick Start Guide V1.0

# Structure


Top Panel
× 44
Lid Slot
× 44
Lid Tab
Front Panel
Side Panel
Pallet Base

# Dimensions



# Required Tools



# Unboxing

1. Insert the head of a flat screwdriver into the spot where the lid tab and lid slot meet on the crate's steel edge.

2. Pry the tab upward slightly.

3 Put the head into the tab's slot and lift the tab.



4 Tap the tab flat with a hammer so it lines up with the slot.

* Repeat the 4 steps above to flatten all tabs.

5 Place the screwdriver head against the edge of the top panel and push upward to disassemble the panel.

* Repeat this step to open the front and side panel.

6 The unboxing is complete after all panels are disassembled.