Yealink

Unboxing Video

MTower



English|DEUTSCH|FRANÇAIS|ESPAÑOL

Quick Start Guide (V1.2)

CONTENT

English.....1
Deutsch.....6
Français.....11
Español.....16

1 Package Contents

MTower

Bottom Cover



3M Tape

Quick Start Guide



(7.5 m, 24.60 ft)
CAT5e Cable

WH-85*3.0mm
Screwdriver

2*6KMOZN3+

Desktop Bracket A
(Thread: ϕ48)



Desktop
Bracket B

Desktop Drilling
Guide Sticker

Note: We recommend that you use the accessories provided or approved by Yealink. The use of unapproved third-party accessories may result in poor performance.

2 Hardware Introduction



No.	Name	Description
①	Camera	Camera.
②	Privacy Cap	Automatically covers the camera when it is turned off.
③	Mute Button & Mute LED Indicator	Touch to mute or unmute.
④	Camera Button & Camera LED Indicator	Turn the camera on/off.
⑤	VCH Port	Connect the endpoint.
⑥	Reset Button	Reset to factory defaults..

EN

3 *LED Indicator*

• Mute LED indicator

LED Status	Description
Off	The device is idle/sleeping/powered off.
Solid green	Unmuted in the meeting.
Flash green	Incoming call.
Solid red	Muted in the meeting.
Flash red	The device is entering recovery mode for firmware upgrade.
Solid orange	The device is starting up.
Flash orange	The firmware is updating.

• Camera LED indicator

LED Status	Description
Off	The device is powered off. The device is idle. The camera privacy cover is closed.
Solid white	The camera privacy cover is open in the meeting.

4 *Installation*

1. Install MTower in the center of the table.
2. Turn the black marking "Towards TV" towards the TV.



This is only a placeholder. For connection steps, please refer to the "5 Connection" section below.

• Paste on a table

1 Connect the network cable.

2 Secure the bottom cover with the screws.

3 Paste with 3M tape.

4 Paste MTower to the table.









• Desktop Bracket

1 Connect the network cable.

2 Install the Desktop Bracket A and the Bottom Cover.

3 Pass the network cable through the Desktop Bracket A.







4 Secure the bottom cover with the screws.

5 Stick the Guide Sticker in the center of the desktop, and drill holes on the desktop according to the hole position on the guide sticker. Insert Desktop Bracket A through the hole.

6 Fix the MTower to the desktop by rotating the Desktop Bracket B.





5 Connection

MTower needs to be used with Yealink host. When the host power adapter meets the voltage of 48V and the current is greater than or equal to 1.36A, MTower does not need additional power supply. When the current is less than 1.36A, MTower needs to be connected to an additional PoE adapter or PoE switch to provide sufficient power for MTower. The following takes SmartVision 40 connection as an example.

- If SmartVision 40 is used with a 48V/1.36A power adapter, MTower does not require additional power supply.

1 Connection method 1: Directly connect to SmartVision 40 via CAT5e cable.



2 Connection method 2: Connect to SmartVision 40 via a Normal Switch/PoE Switch.



- If SmartVision 40 is used with a 48V /0.7A power adapter, it is recommended that MTower connect to the host via a PoE switch.

1 Connection method 1: Connect to SmartVision 40 with a PoE adapter.



2 Connection method 2: Connect to SmartVision 40 with a PoE switch.



3 Connection method 3: Connect to SmartVision 40 with a PoE adapter and switch.



1. When connecting to a normal switch, you need to connect a PoE adapter for the power supply; when connecting to a PoE switch, you don't need to connect a PoE adapter.
2. To avoid the human image in the TV affecting the tracking effect, you can check whether the image meets the requirement in Yealink Roomconnect after the device is deployed, if not, it can be further deployed by setting up the shielding area.

About Yealink

Yealink (Stock Code: 300628) is a global-leading provider of Unified Communication & Collaboration Solutions specialized in video conferencing, voice communications, and collaboration, dedicated to helping every person and organization embrace the power of "Easy Collaboration, High Productivity".

With best-in-class quality, innovative technology, and user-friendly experiences, Yealink is one of the best providers in more than 140 countries and regions, ranks No.1 in the global market share of IP Phone, and is the Top 5 leader in the video conferencing market (Frost & Sullivan, 2021).

For more information about Yealink, click here.

Copyright

Copyright © 2025 YEALINK(XIAMEN) NETWORK TECHNOLOGY CO., LTD.
All rights reserved. No parts of this publication may be reproduced or transmitted in any form or by any means, electronic or mechanical, photocopying, recording, or otherwise, for any purpose, without the express written permission of Yealink(Xiamen) Network Technology CO., LTD.

Technical Support

Visit Yealink WIKI (http://support.yealink.com/) for firmware downloads, product documents, FAQ, and more. For better service, we sincerely recommend you to use Yealink Ticketing system (https://ticket.yealink.com) to submit all your technical issues.

430104003038

YEALINK NETWORK TECHNOLOGY CO.,LTD.
Web: www.yealink.com
Addr: No.666 Hu'an Rd,Huli District Xiamen City, Fujian, P.R. C
Copyright©2025 Yealink Inc. All rights reserved.