


1 Minimum Requirements

- A display connected to MCore Pro (not included).
- A Microsoft Teams Rooms or Skype® for Business account (not included).
- Wired network environment (not included).


2 Package Contents



SmartVision 40 Package




MCore Pro



(1.8 m, 5.91 ft)

HDMI Cable




(2.1m, 6.89ft)

Power Adapter (19V/4.74A)




(WH-85*3.0mm)

Screwdriver




(150*117*15mm)

Mounting Bracket




x 4

φ6 * 30 mm, white, Polyamide



x 4

4*30 FAHOZN3+ (+)




x 2

3*6PMOZN3+




(W25.4*L50mm,3M)

Velcro




Quick Start Guide

MCore Pro Package




MTouch E2



(7,5m, 24,6ft)

CAT5e UTP (RJ45 - RJ45) Cable




(1,2m, 3,94ft)

USB 3.1 (C - C, HDMI) Cable




(WH-85*3.0mm)

Screwdriver




(116.16 mm * 166.41 mm)

Mounting Bracket



x 4

φ6 * 30 mm, white, Polyamide




x 4

4*30 FAHOZN3+ (+)



x 2

2*6 (mm) KMOZN3 (+)




Quick Start Guide

MTouch E2 Package



MTouch Plus



(7.5m, 24.6ft)

CAT5e UTP (RJ45 - RJ45) Cable




(1.2m, 3.94ft)

USB 3.1 (C - C, HDMI) Cable



(WH-85*3.0mm)

Screwdriver



(207.44 mm * 126.99 mm)

Mounting Bracket



× 4

φ6 * 30 mm, white, Polyamide



× 4

4*30 FAHOZN3+ (+)



× 4

2.5*9.0FMHZN(+)



× 2

M8*60mm,SUS304



(M8,φ30*T2mm, SUS304)



× 2

Washer



× 2


(M8,SUS304)

Wing Nuts



(L200*W62.5*T1.2mm)

Double-Coating Tape




Lock cable buckle



× 4

2.5*8.0PAHOZN3+ (+)




Quick Start Guide

MTouch Plus Package (Optional)

3 Installation

- MCore Pro supports: mount on the wall, mount on the TV, stick to the table.
- MTouch E2 supports: put on a table, mount on a wall.
- SmartVision 40 supports: put on a flat surface, mount on the wall, embed in the wall, mount on the Tabletop Mount and mount on the Tabletop Mount.
- Install and deploy the accessories in the system according to the environment and actual needs. For how to install and deploy, please refer to the quick start guide of each product.

4 Connection



- When starting up the system for the first time, you need to connect a mouse to complete the initial configuration. We recommend using the wireless mouse and keyboard kit.
- Not included accessories requirements:
 - » Display: Resolution of 1080p or higher and with an HDMI port.
 - » PC: Equipped with HDMI or USB-C (support DP protocol) Port.
 - » Ethernet cable: CAT5e or higher ethernet cable.
 - » HDMI: Standard HDMI cable.
 - » PoE switch: If you use PoE to connect speakers or cameras, you need to use PoE+.

5 Initial Setup

1. Press the power button on the bottom left of MCore Pro, and the Microsoft Windows 11 IoT Enterprise Edition operating system will be automatically loaded after starting MCore Pro.

Note: When starting up the system for the first time, you need to connect a mouse to complete the initial configuration. We recommend using the wireless mouse and keyboard kit.

After the system is initialized, you can use MTouch E2 to complete the system login and settings, and the device will automatically start the Microsoft Teams conference system application and enter the setting page.

2. Select the check box on the **EULA** page, and then tap **Next**.
3. Enter the account, the password on the **Account** page, and then tap **Next**. Supports Microsoft Teams Rooms or Skype® for Business accounts.
4. On the **Advanced** page, configure the domain and tap **Next**.
5. Tap **Finish** to complete the setup wizard.

6 Features

Control SmartVision 40 Camera Position

1. Tap **More** >  to enter the Camera Control page.