




Wireless Video Conferencing Microphone Array VCM36-W Pro Package

Quick Start Guide

V1.1

Contents

01 English	03
02 Deutsch	06
03 Français	09
04 Español	12



Package Contents




VCM36-W Pro

(1.2 m, 3.94 ft)
USB 2.0 (A - C)
CablePower Adapter
(5 V/2 A
USB-A)(φ50*Τ1.55 mm)
Double-sided
adhesiveCharging
Cradle (USB-C)Quick Start
Guide

Component Instruction



Charge the VCM36-W Pro



Power on/off

1. Long tap the mute button for 5 seconds to power on the VCM36-W Pro.
2. Long tap the mute button for 15 seconds to power off the VCM36-W Pro.
The Charging LED indicator glows red and then off.

Pair the VCM36-W Pro

Pair directly

1. Connect the USB-C port on the VCM36-W Pro to the USB port on the host using the USB-C cable.
The Mute LED indicator slowly flashes orange during pairing. The display device will show: Wireless microphone is paired successfully.
2. Disconnect the cable, then you can use the VCM36-W Pro.

Pair by Yealink RoomConnect

1. Connect the USB-C port on the VCM36-W Pro to the USB port on the PC using the USB-C cable.
2. Connect the Video Out port on the camera/AVHub to the same PC using the USB-B cable.
3. Run the Yealink RoomConnect software on the PC.
The Mute LED indicator slowly flashes orange during pairing. After paired successfully, the VCM36-W Pro card appears on the Yealink RoomConnect software.
4. Disconnect the cable, then you can use the VCM36-W Pro.

Mute or Unmute the VCM36-W Pro

1. Tap the mute button to mute it.
The mute LED indicator glows red.
2. Tap the mute button again to unmute it.

LED Instruction

Charging LED indicator

LED Status	Description
Solid red	Charging.
Fast flashing red	Installing the upgrade package.
Slowly flashing red	Low battery.
Solid green	Charging complete.
Off	Not charging.

Mute LED indicator

LED Status	Description
Solid red	The VCM36-W Pro is muted.
Fast flashing red	Downloading the upgrade package.
Solid orange	VCM36-W Pro is not selected.
Slowly flashing orange	Connecting to the host.
Solid green	The VCM36-W Pro is unmuted.
Slowly flashing green	Incoming call.
Flashing red and green alternately	Locating the device.
Off	• VCM36-W Pro is not powered on. • VCM36-W Pro is not started. • VCM36-W Pro is in sleep mode.

Upgrade the VCM36-W Pro

If the host has a built-in wireless microphone firmware after pairing with VCM36-W Pro successfully, the VCM36-W Pro will be upgraded automatically.

ⓘ Note: Make sure the VCM36-W Pro has enough power before upgrading.


Paketinhalt



VCM36 - W Pro

(1,2 m, 3,94 ft)
USB 2.0 (A - C)
KabelNetzadapter
(5 V/2 A USB -
A)(φ50*Τ1,55 mm)
Doppelseitig
KlebstoffLadestation
(USB - C)Schnellstart-
anleitung

Bauteilanweisung



Laden Sie den VCM36 - W Pro auf

