Controller Quick User Guide for Microsoft Teams

Teams Rooms Interface

To enter the Microsoft Teams Rooms (MTR) interface, switch the system to Microsoft Teams mode. For more information, refer to Switch Account.



No.	Description
1	Scan the QR code to join your meeting with this room.
2	The local time.
3	The username and account number.
4	Start an instant meeting.
5	Make a phone call or call someone to join the meeting.
6	Start/Stop sharing.
7	Navigate to Camera Control, Mic Control, Status, Device Settings, and more.
8	Enter a meeting ID and meeting passcode to join a scheduled meeting.
9	Access additional settings, including Accessibility, Language, Restart Device, and other options.

Teams Rooms Meeting Interface

Switch the system to Microsoft Teams mode. For more information, refer to Switch Account. During a meeting, you can see the following user interface.



No.	Description
1	The local time.
2	The username.
3	Displays the meeting name and meeting ID.
4	Invite someone or dial a number.
5	Displays the list of participants, and you can do operations such as muting.
6	Meeting controls toolbar.

General Feature

When the administrator completes the Quick Setup, the device can start working properly.

Description	Related Document
Start an instant meeting	Instant Meeting
Join the meeting	Join Meeting
Start sharing via a cable	Share Content via Cable

Start sharing via the Yealink Wireless Presentation Pod	Share Content via Yealink Wireless Presentation Pod
Camera control	General Settings